

CLEANING INFORMATION

The FreshWorks™ Produce Saver is stored and washed like a traditional food box, no special treatment necessary.

Does the filter need to be removed for cleaning?

No, the filter never needs to be removed from the lid.

What if something falls down into the filter?

The green filter cover has drain holes along the perimeter, allowing any debris that falls down into that area to be flushed out when put through the dishwasher.


Is this product NSF certified?

Yes, NSF has reviewed the product and certified that it follows all necessary cleanability standards to be used in contact with food in a commercial kitchen.



THE FILTER

Regulates the flow of oxygen and ethylene to create the optimal environment to store fruits and vegetables.



What is it made of?

100% non-woven polyester with a silicone coating.


Think of this as an extremely thin piece of plastic. It's able to filter out tiny particles in the air, but things like water and small debris can't pass through.

Does the filter need to be changed?

The silicone coating doesn't deteriorate over time, so you won't need to change or replace it.

THE RESULTS

Keep produce fresher longer*, allowing you to throw away less and save more.



*Based on produce stored in RCP FreshWorks™ Produce Saver vs traditional food box.