

## PREPARING DISPOSABLE MICROFIBER CLOTHS

HYGEN™ Disposable Microfiber Cloths remove 99.7% or more of tested viruses and bacteria\* with water.





REMOVE HYGEN™
Disposable Microfiber cloths out of the plastic bag and place all cloths into the Charging Bucket.





**ADD** water or cleaning solution over cloths and into Charging Bucket. Use 40oz of solution when using full pack of cloths.



**CLOSE** lid of the Charging Bucket and open cloth dispenser as cloths are ready to be used.



HYGEN™ Disposable Microfiber is safe to use with common cleaning disinfectants such as Quat, Chlorine Bleach and Hydrogen Peroxide.

ITEM #	ITEM DESCRIPTION	PACK QTY	RECOMMENDED MAX SOLUTION*
2134283	HYGEN™ Disposable Microfiber Cloth 12" × 12"	60	40 oz   1200 ml
2135007	HYGEN™ Charging Tub for Cloth	-	-

<sup>\*</sup>per max cloths





## PREPARING DISPOSABLE MICROFIBER PADS

Preparing HYGEN™ microfiber mop pads prior to use ensures they are properly moistened to cover up to 250sq ft.



ADD water and/or cleaning solution to the Charging Bucket. The bucket design features an internal measuring guide. Each graduated step inside the Charging Bucket represents one guart.





PLACE disposable microfiber pads in the Charging Bucket with the HYGEN™ logo back side of the pad facing upwards. Each bucket holds 50 microfiber pads.



**SECURE** leak-proof lid to the Charging Bucket by snapping the end and side tabs into place.



FLIP Charging Bucket upside down and leave it upside-down for 5-10 minutes. This allows the cleaning solution to saturate all of the mops. The pads are now ready to use.



The Charging Bucket for the Disposable Microfiber cloths and pads fits with the High-Security Cart and High-Capacity Janitorial Cleaning Cart.

ITEM #	ITEM DESCRIPTION	PACK QTY	RECOMMENDED MAX SOLUTION*
2134282	HYGEN™ Disposable Microfiber Pad	50	85 oz   2500 ml
FGQ95088YEL	HYGEN™ Microfiber Charging Bucket, Yellow	-	-

<sup>\*</sup>per max cloths



2134282

FGQ95088YEL